KDM®

PREMIUM MOBILE ACCESSORIES

KDM-E1

ORBITPODS

WIRELESS EARPHONE


SPECIFICATION

Product Code	:	**KDM-E1**
Wireless Version	:	V6.0
Transmission Distance	:	10m
Standby Time	:	Up To 800 Hours
Charging Port	:	Type-C
Battery Capacity	:	300mAh
Music Time	:	Up To 7 Hours*
Talking Time	:	Up To 8 Hours*
Charging Time	:	90 Minutes

**At 40% to 60% volume*


Battery EPRRN: 7257388284581754441

STRUCTURE



WIRELESS PAIRING

- Take the earbuds out of the case, they will automatically enter wireless pairing mode.
- Go to wireless settings of your device and search for "**KDM-E1 OrbitPods**", tap on it, once connected will hear a prompt sound.
- When the earpods are used again, they automatically con nects to your last paired device.




NOTE:


Automatic shutdown
when not connected for 5 minutes.

FUNCTIONALITY

ON

OFF





Power On:


Open the charging case or long-press right /left earbud's touch area for 5S.

Power Off:

Put the earbuds back into the charging case or or long-press right /left earbud's touch area for 5S.


- Single Tap
- Double Tap
- Triple Tap
- Long Press

L or R




- **Play/Pause**
- **Answer/Hang Up**
- **Reject Incoming Call 2S**

R



- **Next Song**
- **Volume Down**
- **3S To Switch Between (ANC Mode, Transparency Mode, Music Mode)**

L



- **Previous Song**
- **Volume Up**
- **3S Voice Assistant**

Earbuds Charging

When you put the earbuds into the charging bin, the white light will turn on. After the earbuds are fully charged, the white light will turn off.

Charging In The Charging Compartment

While charging in the charging compartment, the red light flashes on. It turns off about 10 seconds after the headset is fully charged.

Earbuds Low Battery Prompt

Battery is less than 10% white light flashes at one-minute intervals, with a beep tone.

IMPORTANT TIPS

- Do not use this product under high temperature, humidity, cold, dust, electromagnetic radiation, and lightning conditions.
- Always use genuine KDM accessories for charging to ensure safety, better performance, and longer device life.
- Charging time should not exceed the given hours.
- Recharge at least once every 30 days to preserve battery lifespan.
- Do not exceed 60 decibels to avoid hearing damage when using for a long time.
- After the end of its life, the product can be sent to a professional recycling agency, do not discard it at will, so as not to pollute the environment.