

KDM[®]
PREMIUM MOBILE ACCESSORIES

KDM-W3
JIYOPODS
WIRELESS EARPHONE


SPECIFICATIONS

Product Code	: KDM-W3
Wireless Version	: V6.0
Transmission Distance	: 10m
Standby Time	: Up To 500 Hours
Charging Port	: Type-C
Battery Capacity	: 250mAh
Music Time	: Up To 5 Hours*
Talking Time	: Up To 6 Hours*
Charging Time	: 90 Minutes

**At 40% to 60% volume*

Battery EPRRN : 7257388284581754441

STRUCTURE



TOUCH AREA


WIRELESS PAIRING

- Take the earbuds out of the case, they will automatically enter wireless pairing mode.
- Go to the wireless settings of your device and search for **"KDM-W3 JIYOPDS"**, tap on it, once connected will hear a prompt sound.
- When the earbuds are used again, they automatically connect to your last paired device.


NOTE:
Automatic shutdown
when not connected for 5 minutes.



FUNCTIONALITY




Power On: Take the earbuds out of the charging case or long-press left/right earbud's touch area for 5S.



Power Off: Put the earbuds back into the charging case or long-press left/right earbud's touch area for 5S.

- Single Tap
- Double Tap
- Triple Tap
- Long Press

L or R



- ▶ **Play/|| Pause**
- 📞 **Answer/📞 Hang Up**
- 📞 **Reject Incoming Call**
- 3S 🗣️ **Voice Assistant**

R



- 🔊 **Volume Down**
- ⏭️ **Next Song**

L



- 🔊+ **Volume Up**
- ⏮️ **Previous Song**

Earbuds Charging

Blue light on charging compartment during earbuds charging
& light goes off while buds fully charged.

Charging In The Charging Compartment

Blue light on charging compartment during earbuds charging
& light goes off while buds fully charged.

Earbuds Low Battery Prompt

Battery is less than 10%, then single prompt tone hear in every 1 minutes intervals.

Restore Factory Settings

When the earbuds are powered on and not connected to the device, the earbuds can be restored to factory setting with four taps. One or both ears can be operated.

IMPORTANT TIPS

- Do not use this product under high temperature, humidity, cold, dust, electromagnetic radiation, and lightning conditions.
- Always use genuine KDM accessories for charging to ensure safety, better performance, and longer device life.
- Charging time should not exceed the given hours.
- Recharge at least once every 30 days to preserve battery lifespan.
- Do not exceed 60 decibels to avoid hearing damage when using for a long time.
- After the end of its life, the product can be sent to a professional recycling agency, do not discard it at will, so as not to pollute the environment.