




KDM-W4
MASTERPIECE
W I R E L E S S E A R P H O N E

SPECIFICATIONS

Product Code	:	KDM-W4
Wireless Version	:	V5.4
Battery Capacity	:	300mAh
Transmission Distance	:	10m
Music Time	:	Up To 5 Hours*
Talking Time	:	Up To 6 Hours*
Standby Time	:	Up To 560 Hours
Charging Time	:	120 Minutes
Charging Port	:	Type-C

**At 40% to 60% volume*

STRUCTURE



WIRELESS PAIRING

- Take the earbuds out of the case, they will automatically enter wireless pairing mode.
- Go to the wireless settings of your device and search for **"KDM-W4 MASTERPIECE"**, tap on it, once connected will hear a prompt sound.
- When the earbuds are used again, they automatically connect to your last paired device.

NOTE:
Automatic shutdown
when not connected for 5 minutes.



FUNCTIONALITY



Power On: Open the charging case lid or long-press left/right earbud's touch area for 5S.



Power Off: Put the earbuds back into the charging case or long-press left/right earbud's touch area for 5S.

- Single Tap
- Double Tap
- Triple Tap
- Four Taps
- Long Press

L or R



- ▶ **Play/|| Pause**
- 📞 **Answer/📞 Hang Up**
- 📞 **Reject Incoming Call**
- 3S, 🗣️ **Voice Assistant**
- 🎮 **Gaming Mode On/Off**

R



- 🔊 **Volume Down**
- ⏭️ **Next Song**

L



- 🔊 **Volume Up**
- ⏮️ **Previous Song**

Anti-lost Mode

When your device is out of wireless range, earbuds will give an alert to ensure your device is with you. (Voice Prompt: Connection lost, find your device)

Earbuds Charging

The white light of the earbuds is always on while charging and light goes off once fully charged.

Charging In The Charging Compartment

The white light flashes slowly during charging and the white light is always on when it is fully charged.

Earbuds Low Battery Prompt

Battery is less than 10%, red light breathing flashes at one-minute intervals with a beep tone.

Restore Factory Settings

When the earbuds are powered on and not connected to the device, the earbuds can be restored to factory setting with four taps. One or both ears can be operated.

IMPORTANT TIPS

- Do not use this product under high temperature, humidity, cold, dust, electromagnetic radiation, and lightning conditions.
- Always use genuine KDM accessories for charging to ensure safety, better performance, and longer device life.
- Charging time should not exceed the given hours.
- Recharge at least once every 30 days to preserve battery lifespan.
- Do not exceed 60 decibels to avoid hearing damage when using for a long time.
- After the end of its life, the product can be sent to a professional recycling agency, do not discard it at will, so as not to pollute the environment.



with
KDM
PREMIUM MOBILE ACCESSORIES



@KDMINDIA

Scan QR Code
To Join The KDM Klub.

www.kdmindia.in