

KDM[®]
PREMIUM MOBILE ACCESSORIES

KDM-Z4
JACKPODS
WIRELESS EARPHONE

SPECIFICATIONS

Product Code : **KDM-Z4**

Wireless Version : **V5.4**

Battery Capacity : **250mAh**

Transmission Distance : **10m**

Music Time : **Up To 5 Hours***

Talking Time : **Up To 6 Hours***


Standby Time : **Up To 500 Hours**

Charging Time : **90 Minutes**

Charging Type : **Type-C**

**At 40% to 60% volume*

STRUCTURE




WIRELESS PAIRING

- Take the earbuds out of the case, they will automatically enter wireless pairing mode.
- Go to the wireless settings of your device and search for **"KDM-Z4 JACKPODS"**, tap on it, once connected will hear a prompt sound.
- When the earbuds are used again, they automatically connect to your last paired device.

NOTE:
Automatic shutdown
when not connected for 5 minutes.



FUNCTIONALITY



Power On: Take the earbuds out of the charging case or long-press left/right earbud's touch area for 5S.



Power Off: Put the earbuds back into the charging case or long-press left/right earbud's touch area for 5S.

- Single Tap
- Double Tap
- Triple Tap
- Long Press

L or R



- ▶ **Play/|| Pause**
- 📞 **Answer/📞 Hang Up**
- 📞 **Reject Incoming Call**
- 3S, 🗣️ **Voice Assistant**

R



- 🔊 **Volume Down**
- ⏭️ **Next Song**

L



- 🔊 **Volume Up**
- ⏮️ **Previous Song**

Earbuds Charging

The white light of the earbuds is always on while charging and the light goes off once fully charged.

Charging In The Charging Compartment

The red light is blinking while charging. When the battery is full, the red light is steady on.

Earbuds Low Battery Prompt

Battery is less than 10%, green light breathing flashes & a single prompt tone at one-minute intervals.

Restore Factory Settings

When the earbuds are powered on and connected to the device, the earbuds can be restored to factory settings with four taps. One or both ears can be operated.

IMPORTANT TIPS

- Do not use this product under high temperature, humidity, cold, dust, electromagnetic radiation, and lightning conditions.
- Always use genuine KDM accessories for charging to ensure safety, better performance, and longer device life.
- Charging time should not exceed the given hours.
- Recharge at least once every 30 days to preserve battery lifespan.
- Do not exceed 60 decibels to avoid hearing damage when using for a long time.
- After the end of its life, the product can be sent to a professional recycling agency, do not discard it at will, so as not to pollute the environment.



with
KDM[®]
PREMIUM MOBILE ACCESSORIES



Scan QR Code
To Join The KDM Klub.

www.kdmindia.in