KDM®

PREMIUM MOBILE ACCESSORIES

KDM-30

# AUDIORISE

WIRELESS SPEAKER

# SPECIFICATION

| | | |
|---|---|---|
| **Product Code** | : | KDM-30 |
| **Wireless Version** | : | V5.4 |
| **Transmission Distance** | : | 10M |
| **Output Power** | : | 5W*2 |
| **Speaker Size** | : | 4 inch*2 |
| **Battery Capacity** | : | 1500mAh |
| **Music Time** | : | Upto 6 Hours* |
| **Charging Port** | : | Type-C |
| **Charging Time** | : | 100 minutes |
| **Support** | : | USB, TF, FM, TWS |

*At 40% to 60% volume while RGB Lights off

# STRUCTURE




# WIRELESS PAIRING

- Power on the speaker, it automatically enters wireless pairing mode,
- Go to device wireless settings, search for **"KDM-30 AudioRise"**, and click to connect, on successful connection will hear a prompt sound.
- When the speaker is used again, it automatically connects to your last paired device.

Note: This product does not support charging while playing, when the power is too low, please turn off the device and charge it in time, until the charging indicator is off, you can turn on and continue to use.



# SPEAKER FUNCTIONALITY




● Single Tap ●● Double Tap ▬ Long Press

1 **MODE** ● ○ Switch Mode (Wireless/TF/USB/FM)

2 / V− ● Previous Track

▬ Volume Down

3 / ● Play / ❙❙Pause/Search Station Automatically ( In FM Mode)


●● TWS Function

4 / V+ ● Next Track

▬ Volume Up

5 ● Switch RGB Modes & RGB On/Off

# SPEAKER FUNCTIONALITY




6 ..... Power On/Off

7 ..... Type-C Charging Port

8 ..... TF Card Slot

9 ..... USB Port

# MIC FUNCTIONALITY

1 — On/Off


2 — Volume Up

3 — Volume Down


4 — Voice Change Feature
(5 Voices Including Original)
Voice Change Feature On/Off

5 — Indicator

6 — Type-C Charging Port



# 1+1 TWS OPERATION




1. 1+1 enables you to pair two speakers wirelessly by turning on both KDM-30 AudioRise speakers. First connect one of them and play music, Then double-click the ⏯ button on the other KDM-30 AudioRise speaker to connect successfully.
2. The optimal connection distance betwwen two speakers is about 5 meters.

# IMPORTANT TIPS

- Do not use this product under high temperature, humidity, cold, dust, electromagnetic radiation, and lightning conditions.
- Always use genuine KDM accessories for charging to ensure safety, better performance, and longer device life.
- Charging time should not exceed the given hours.
- Recharge at least once every 30 days to preserve battery lifespan.
- Do not exceed 60 decibels to avoid hearing damage when using for a long time.
- After the end of its life, the product can be sent to a professional recycling agency, do not discard it at will, so as not to pollute the environment.


KARO
DIL KI
MARZI
with
KDM
PREMIUM MOBILE ACCESSORIES